

How to build your own Multitest II programing cable using a phone extension cord and a connector from a XR/NR receiver



Disassemble any extra XR/NR receiver and remove it's connector.

Holding the connector as show, all wires line up.

Left pin on phone jack goes to left pin on Antenna connector and so on.

Get a Phone jack or Phone extension cord and cut one end of it

